

UCRL-91877
PREPRINT

CIRCULATION COPY
SUBJECT TO RECALL
IN TWO WEEKS

SPLINES REVISITED

F. N. Fritsch

**This paper was prepared for presentation at
NASIG'84 -- Argonne National Laboratory
September 18-19, 1984**

September 1984

**Lawrence
Livermore
National
Laboratory**

**This is a preprint of a paper intended for publication in a journal or proceedings. Since
changes may be made before publication, this preprint is made available with the un-
derstanding that it will not be cited or reproduced without the permission of the author.**

DISCLAIMER

This document was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor the University of California nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial products, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or the University of California. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or the University of California, and shall not be used for advertising or product endorsement purposes.

SPLINES REVISITED*

This report is a reproduction of slides used in a talk given 18 September 1984 at NASIG'84.

ABSTRACT

The Fowler-Wilson spline, long used in the CAM system APT, and the beta-spline, recently introduced for computed-aided curve and surface design, are defined and compared. These "splines" are also compared with the more familiar cubic B-splines.

***This work was performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under contract No. W-7405-Eng-48.**

**Frederick N. Fritsch
Mathematics & Statistics Division
Lawrence Livermore National Laboratory**



Splines Revisited

or

Just What Is This Alphabet Soup?

Outline



- 1. History of splines**
- 2. Cubic splines**
- 3. General piecewise polynomial functions; B-splines**
- 4. Parametric splines; B-spline curves.**
- 5. Interactive design of curves**
- 6. β -splines**
- 7. The Fowler-Wilson spline**
- 8. Connections between F-W and other splines**

A Brief History of Splines

Reference: L. Schumaker, *Spline Functions: Basic Theory*, Wiley, 1981



- **Mathematical model for the mechanical spline.**
[Ahlberg; Nilson; Schoenberg; Walsh - early 1960's]
- **General piecewise polynomial functions; B-splines.**
[deBoor; Cox - early 1970's]
- **Parametric splines; B-spline curves.**
[various systems for designing curves/surfaces]
- **Generalizations: splines under tension; ν -splines; L-splines; . . . ; β -splines [Barsky - 1981]**
- **Nonlinear splines.**
[Fowler&Wilson - 1963; Birkhoff,Burchard,Thomas - 1965; Lee&Forsythe - 1973; Mehlum - 1974].




Figure 2. The mechanical spline.

[From Schumaker, op. cit., p. 6.]

Cubic Splines



Given: $x_1 < x_2 < \dots < x_n$; $y_i = f(x_i)$, $i=1, \dots, n$.

- $s(x)$ is a cubic polynomial in each subinterval $[x_i, x_{i+1}]$.
- $s(x)$, $s'(x)$, $s''(x)$ are all continuous on $[x_1, x_n]$.

Properties:

- Two degrees of freedom (BC) for interpolation problem:


$$s(x_i) = y_i \quad i = 1, \dots, n.$$

- "Natural" spline, with $s''(x_1) = s''(x_n) = 0$, minimizes

the "energy" integral, $\int [f''(x)]^2 dx$.

- Solve diagonally-dominant tridiagonal linear system.

A Typical Cubic Spline




General Piecewise Polynomial Functions



- $s(x)$ is a polynomial of order k (degree $\leq k-1$) in $[x_i, x_{i+1}]$.
- Arbitrary continuity requirements at x_2, \dots, x_{n-1}
[maximum $(k-2)$ nd derivative, else "not a knot"].
- B-splines provide a stable basis for computation
(B-spline package):
 1. $s(x) = \sum c_j B_j(x)$.
 2. $B_j(x) \geq 0$; $B_j(x) = 0$ except on k intervals.
 3. $\sum B_j(x) = 1$.
- Solve (diagonally-dominant) banded linear system.

A General Piecewise Polynomial Function

($k \geq 4$)






Figure 10. The B-splines N^3 and N^4 .

[From Schumaker, op. cit., p. 136.]

B-SPLINES

123












Figure 7. Shapes of some B-splines.

[From Schumaker, op. cit., p. 123.]


Parametric Splines




Given: P_1, P_2, \dots, P_n ; $P_i = (x_i, y_i)$, $i=1, \dots, n$.

- **View as a collection of points in the plane through which a smooth curve is to be drawn. [No implied functional dependence, $y = f(x)$.]**
- **Introduce a parametrization via $t_1 < t_2 < \dots < t_n$.**
- **Define curve via two spline functions in parameter space:**
 $x = f(t); \quad f(t_i) = x_i, i=1, \dots, n$;
 $y = g(t); \quad g(t_i) = y_i, i=1, \dots, n$.
- **B-spline curve if f and g are B-splines.**
[Typically, f and g are quadratic or cubic splines.]


A Typical Parametric Spline



$$y = f(x)$$



$$x = f(y)$$




Parametric cubic spline plot code -- version 9
LLL benchmark test (selected) -- x,y -- default end conditions

ibeg = 0, vbeg = 0.

iend = 0, vend = 0.

npar = 1

Curve and Data Points




Parametric cubic spline plot code -- version 9
LLL benchmark test (selected) -- x,y -- default end conditions

ibeg = 0. vbeg = 0.


iend = 0. vend = 0.

npar = 1

x component vs parameter t



y component vs parameter t



Interactive Design of Curves



- Change of motivation: design of free-form curves (rather than interpolation of "hard" data).

- Control polygon $Q = Q_1 Q_2 \dots Q_m$:

$Q_j = (a_j, b_j)$, where

$$\begin{aligned} x &= f(t) = \sum a_j B_j(t) ; \\ y &= g(t) = \sum b_j B_j(t) . \end{aligned}$$

- Curve $P(t) = (f(t), g(t))$ mimics the shape of Q .
- Extends naturally to more independent variables.


Parametric cubic spline plot code -- version 12
LLL benchmark test (selected) -- x,y -- default end conditions

ibeg = 0. vbeg = 0.

iend = 0. vend = 0.

npar = 1

Control Polygon



β -Splines



- Generalization of the cubic B-spline curve, introduced to obtain more local control over shape of curve segments.

- Parametric continuity:

$$(0) \ P^{(0)}(t_i^-) = P^{(0)}(t_i^+) ,$$

$$(1) \ P^{(1)}(t_i^-) = P^{(1)}(t_i^+) ,$$

$$(2) \ P^{(2)}(t_i^-) = P^{(2)}(t_i^+) , \ i=2, \dots, n-1 ,$$

$$\text{where } P^{(k)}(t) = (f^{(k)}(t), g^{(k)}(t)) .$$

- Geometric continuity [Barsky]:

Curve, unit tangent, and curvature continuous on $[t_i, t_n]$.

$$(0) \ P^{(0)}(t_i^-) = P^{(0)}(t_i^+) ,$$

$$(1) \ \beta_{1i} P^{(1)}(t_i^-) = P^{(1)}(t_i^+) ,$$

$$(2) \ \beta_{1i}^2 P^{(2)}(t_i^-) + \beta_{2i} P^{(1)}(t_i^-) = P^{(2)}(t_i^+) .$$

[$2(n-2)$ extra parameters β_{1i} and β_{2i} , $i=2, \dots, n-1$.]




Figure 115. This sequence of curves illustrates the effect of increasing β_1 on a uniformly-shaped Beta-spline.

[From R.H.Bartels, J.C.Beatty, and B.A.Barsky, An Introduction to the Use of Splines in Computer Graphics, University of Waterloo Report CS-83-09, August 1983, p. 160.]







Figure 117. This sequence of curves illustrates the effect of increasing β_2 on a uniformly-shaped Beta-spline.


[From Bartels, Beatty, and Barsky, *op. cit.*, p. 161.]

The Fowler-Wilson Spline



- Generalizes "ordinary" cubic spline to points in plane in a different way. (Back to interpolation of "hard" data.)
- Definition:
 - (1) Use local coordinate system for each curve segment; curve position is cubic in local coordinates.
 - (2) Require continuous tangent direction and curvature at interior points. [Solve tridiagonal *nonlinear* system.]
- History:
 - First described in 1963 Oak Ridge report by A.H.Fowler and C.W.Wilson (with iterative algorithm).
 - Has been in use in APT system since early 1960's.
 - W.R.Melvin studied existence and uniqueness properties, gave much better Newton iteration in 1982 LANL report.


F-W Spline Local Coordinate System



Fowler-Wilson spline plot code -- version 16
LLL benchmark test (selected) -- x,y -- default end conditions

ibeg = 0. entrya = -2.52679e-01 iend = 0. exita = -1.58496e+00 eps = 1.0e-03


Curve and Data Points




Fowler-Wilson spline plot code -- version 16
LLL benchmark test (selected) -- x,y -- default end conditions

ibeg = 0. entrya = -2.52679e-01 iend = 0. exita = -1.58496e+00 eps = 1.0e-03

x component vs parameter t



y component vs parameter t



Connections between F-W and Other Splines



- **F-W spline is a parametric piecewise cubic curve;
it is *not* a parametric cubic spline.
[Component functions not even C^1 .]**
- **Can reparametrize to be C^1 but not C^2 (in general).
[Representable as a B-spline curve with double knots.]**
- **The F-W spline is a β -spline.**